SHARP SERVICE MANUAL

No. S4420CDES9BK/



MINI COMPONENT SYSTEM

MODEL CD-ES9(BK)

CD-ES9 Mini Component System consisting of CD-ES9 (main unit) and CP-ES9 (speaker system).

COMPACT disc DIGITAL AUDIO CD-R/RW Playable 5CD CHANGER

- In the interests of user-safety the set should be restored to its original condition and only parts identical to those specified should be used.

This Service Manual is for the CD-ES9 (BK), which is a minor-modification model of the CD-ES99. This manual, therefore, describes only the changed points from the service manual. Please refer to the CD-ES99, service manual (No. S2405CDES900/) together with this manual.

DIFFERENCE BETWEEN CD-ES99AND CD-ES9 (BK)

REF. NO.	PART NO. ★ CD-ES99		PART NO. ★ CD-ES9 (BK)		DESCRIPTION	CODE
CABINET PARTS						
201	CCABA5529AW01	J	CCABA5986AW01	J	Front Panel Ass'y	
201-1	———		———		Front Panel (Not Replacement Item)	—
201-2	GCōVAA026AWSA	J	Same as CD-ES99		Cover, Cassette [Tape 1]	AG
201-3	GCōVAA027AWSA	J	Same as CD-ES99		Cover, Cassette [Tape 2]	AG
201-4	GDōRF0127AWSA	J	Same as CD-ES99		Holder, Cassette [Tape 1]	AE
201-5	GDōRF0128AWSA	J	Same as CD-ES99		Holder, Cassette [Tape 2]	AE
201-6	HDECQ1108AWSA	J	Same as CD-ES99		Panel, Cassette [Tape 1]	AE
201-7	HDECQ1109AWSA	J	Same as CD-ES99		Panel, Cassette [Tape 2]	AE
201-8	JKNBZA022AWSA	J	Same as CD-ES99		Button, Disc Number	AF
201-9	MLiF-A001AWZZ	J	Same as CD-ES99		Damper	AD
201-10	JKNBZA023AWSA	J	Same as CD-ES99		Button, Operation A	AM
201-11	JKNBZA024AWSA	J	Same as CD-ES99		Button, Operation B	AM
201-12	JKNBZ0985AWSA	J	Same as CD-ES99		Button, Function	AE
201-13	JKNBZA026AWSA	J	Same as CD-ES99		Button, Memory	AF
201-14	JKNBZA027AWSA	J	Same as CD-ES99		Button, Tuning	AF
201-15	JKNBZA030AWSA	J	Same as CD-ES99		Button, Power	AG
201-16	GCōVA1533AWSA	J	Same as CD-ES99		Cover, Timer	AC
201-17	HBDGB1007AWSA	J	Same as CD-ES99		Badge, SHARP	AD
201-18	MSPRDA002AWFJ	J	Same as CD-ES99		Spring, Cassette [Tape 1]	AB
201-19	MSPRDA003AWFJ	J	Same as CD-ES99		Spring, Cassette [Tape 2]	AB
201-20	HDECQ1105AWSA	J	Same as CD-ES99		Volume Knob Ring, A	AG
201-21	HDECQ1106AWSA	J	Same as CD-ES99		Volume Knob Ring, B	AF
201-22	HDECQA015AWSA	J	HDECQA058AWSA	J	Decoration Plate, Amp	AH
201-23	MLōKC0014AWZZ	J	Same as CD-ES99		Lock, Cassette [Tape 1]	AC
201-24	MLōKC0015AWZZ	J	Same as CD-ES99		Lock, Cassette [Tape 2]	AC
201-25	MSPRD0196AWFJ	J	Same as CD-ES99		Spring, Cassette Lock [Tape 1]	AB
• 201-26	MSPRD0197AWFJ	J	Same as CD-ES99		Spring, Cassette Lock [Tape 2]	AC

★ MARK: SPARE PARTS-DELIVERY SECTION

SHARP CORPORATION

This document has been published to be used for after sales service only.
The contents are subject to change without notice.

CD-ES9

REF. NO.	PART NO. ★ CD-ES99	PART NO. ★ CD-ES9 (BK)	DESCRIPTION	CODE
ACCESSORIES				
	TiNSEA002AWZZ J	TiNSEA055AWZZ J	Operation Manual	AE
	TiNSZA003AWZZ J	TiNSZA069AWZZ J	Quick Guide	AD

★ MARK: SPARE PARTS-DELIVERY SECTION

DIFFERENCE BETWEEN CP-MPS99 AND CP-ES9(BK)

REF. NO.	PART NO. ★ CP-MPS99	PART NO. ★ CP-ES9(BK)	DESCRIPTION	CODE
SPEAKER BOX PART				
907	TSPC-A013AWZZ J	TSPC-A039AWZZ J	Label, Specifications	

★ MARK: SPARE PARTS-DELIVERY SECTION

CD-ES9 : Changed



Figure 3 CABINET EXPLODED VIEW

PACKING OF THE SET

Setting position of switches and knobs	
Tape Mechanism	STOP



SHARP

: Changed

COPYRIGHT © 2004 BY SHARP CORPORATION

ALL RIGHTS RESERVED.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any from or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher.

SHARP CORPORATION
AV Systems Group
Quality & Reliability Control Center
Higashihiroshima, Hiroshima 739-0192, Japan

Printed in Japan

A0404-	**DS•HA•M**

SC